

CVX 02 Professional: Firmware Update

Please install this software update to boost the performance of your CVX 02 system. This may affect devices with the following type numbers:

7 607 276 016, 7 607 276 017, 7 607 276 018, 7 607 276 019

To find out whether or not the firmware update is required or recommended for your system, read out the version of the software currently installed on your device:

Which software version is installed on my CVX 02 device?

1. Press buttons "4" and "MON" simultaneously to activate the Service menu.
2. Press button "4" again to have the current software version displayed.

Note: Please do **not** update your software if the version "061107A0" or "081020A0" is displayed already.

- a) If the software version displayed on your CVX 02 is "080408A0" (8 April 2008) or "080812A0" (12 August 2008), then it is recommended to update your SW to version "081020A0" (20 October 2008).
 - b) If the software version of your CVX 02 is different to "061107A0" (7 November 2008), then it is recommended to update your system to "061107A0".
3. Leave the Service menu by pressing buttons "4" and "AM" simultaneously.

Which hardware is required?

- PC with CD writer
- Blank CD (CD-R, do not use RW disk)

Getting started:

1. Download the corresponding ISO image (see above, case a or b) from the homepage.
2. Burn this image file onto a blank CD to create your own download/update disk.

CVX02 update:

1. Insert your update CD into the CVX02.
2. Press "OK" on the remote control to start the update process.
Note: The display shows "Press Play to begin"; please ignore this message and press the "OK" button to start the process.
3. The download process takes approx. 2 min. If the download is not initiated automatically, please remove the disk from the drive and start with 1. again.
4. Please remove the CD from the drive after the download has finished.